



Directions for Adding a Remote

1. Locate the Encryptor box (small white box pictured below)
2. On the top of the Encryptor box, there is a small black button. Press this button one time. A red LED light should come on and stay solid.
3. Press the lock button 3 times on your new key fob.
4. Look to see if the LED light on the Encryptor has gone off. If so, then your new remote is programmed.
5. Test your new remote.



Should you need further assistance, please contact our office at 803-648-4980.