



Directions for Using Remote Button



ARM AWAY: Press large blue button one time. LED indicator light outside your home should flash red.

ARM PERIMETER ONLY: Press large blue button and hold for 3 (three) seconds. LED indicator light should stay solid red.

DISARM: Press large blue button one time. LED indicator light should turn off.

PANIC: Press and hold small red button for 3 (seconds).

Should you need further assistance, please contact our office at 803-648-4980.